

# Trailer Service Schedule



**BUILDING & HIRING**  
**TRAILERS OF DISTINCTION**

## BEFORE EACH JOURNEY

- ☐ Check the trailer visually for damage
- ☐ Check connection to towing vehicle
- ☐ Check tyre tread, side wall and pressures
- ☐ Check road light for damage and functionality

## AFTER THE FIRST 500 MILES OR 1 MONTH

(In addition to the above)

- ☐ Re-torque wheel nuts/bolts
- ☐ Check/re-adjust braking system
- ☐ Check wheel hub for side play

## AFTER EVERY 3000 MILES OR 3 MONTHS

(In addition to the above)

- ☐ Check/re-adjust braking system

## AFTER EVERY 12000 MILES OR 12 MONTHS

(In addition to the above)

- ☐ Lubricate the 50mm ball head (if fitted) **NB DO NOT GREASE A DRY BALL STABILISER**
- ☐ Check/lubricate jockey wheel and/or prop stand
- ☐ Apply grease to overrun coupling grease nipples

## AFTER EVERY 24000 MILES OR 24 MONTHS

(In addition to the above)

- ☐ Check/clean/re-grease wheel hub bearings

## BODYWORK CHECKS EVERY 12 MONTHS

- ☐ Check the sealant and seals on bodywork